

arantia.

Chronos STB Quick Installation Guide

The box must contain the following elements:

- Arantia Chronos set-top box (STB)
- External 12V/1.5A Power Supply
- HDMI 1.5m (4 feet) cable
- USB memory stick

In order to achieve a correct connection of the set-top box please follow the steps below:

1. Plug one end of the HDMI cable into the STB's HDMI socket and the other end into one of the TV's HDMI sockets.
2. Connect the RJ45 socket of the STB to the local Ethernet network.
3. Connect the round plug of the External 12V/1.5A Power Supply to the STB and the power plug to the mains power.
4. Turn the TV on and select the HDMI input corresponding to the Chronos STB as in step 1.

IMPORTANT: DS-SYNC requires an external USB-attached memory stick or disk drive in which to store the contents for Digital Signage. Please insert the USB memory at either the frontal or rear USB connector and read the **Status LED of the Chronos set-top box** according to the table below.



Location of the Status LED at the frontal panel of the Chronos set-top box

LED Pattern	Meaning. How to proceed
●	Idle. Please insert a blank USB memory drive. CAUTION! PREVIOUS CONTENTS OF THE USB DRIVE (IF ANY) WILL BE ERASED PERMANENTLY AFTER INSERTION. PLEASE USE ONLY NEW, BLANK DRIVES SPECIFICALLY INTENDED FOR DS-SYNC USAGE.
●	Playing. The schedule is running.
● ● ● ●	Erasing. Please do not remove the USB drive or shut-down the STB at this point.
● ● ● ●	Synchronizing. Please do not remove the USB drive or shut-down the STB at this point.

To start using Arantia Digital Signage please log-in at the web application: [<http://ds.arantia.com:8090/>]

Download the full player's intallation guide at: [http://ds.arantia.com:8090/docs/ArantiaDS_RS_DSSYNC_EN.pdf]

Download the full user's guide at: [http://ds.arantia.com:8090/docs/DS_User_Guide_EN.pdf]

arantia.

Chronos STB Quick Installation Guide

The box must contain the following elements:

- Arantia Chronos set-top box (STB)
- External 12V/1.5A Power Supply
- HDMI 1.5m (4 feet) cable
- USB memory stick

In order to achieve a correct connection of the set-top box please follow the steps below:

1. Plug one end of the HDMI cable into the STB's HDMI socket and the other end into one of the TV's HDMI sockets.
2. Connect the RJ45 socket of the STB to the local Ethernet network.
3. Connect the round plug of the External 12V/1.5A Power Supply to the STB and the power plug to the mains power.
4. Turn the TV on and select the HDMI input corresponding to the Chronos STB as in step 1.

IMPORTANT: DS-SYNC requires an external USB-attached memory stick or disk drive in which to store the contents for Digital Signage. Please insert the USB memory at either the frontal or rear USB connector and read the **Status LED of the Chronos set-top box** according to the table below.



Location of the Status LED at the frontal panel of the Chronos set-top box

LED Pattern	Meaning. How to proceed
●	Idle. Please insert a blank USB memory drive. CAUTION! PREVIOUS CONTENTS OF THE USB DRIVE (IF ANY) WILL BE ERASED PERMANENTLY AFTER INSERTION. PLEASE USE ONLY NEW, BLANK DRIVES SPECIFICALLY INTENDED FOR DS-SYNC USAGE.
●	Playing. The schedule is running.
● ● ● ●	Erasing. Please do not remove the USB drive or shut-down the STB at this point.
● ● ● ●	Synchronizing. Please do not remove the USB drive or shut-down the STB at this point.

To start using Arantia Digital Signage please log-in at the web application: [<http://ds.arantia.com:8090/>]

Download the full player's intallation guide at: [http://ds.arantia.com:8090/docs/ArantiaDS_RS_DSSYNC_EN.pdf]

Download the full user's guide at: [http://ds.arantia.com:8090/docs/DS_User_Guide_EN.pdf]