

## Secvest Wireless Control Device

Art.-Nr. FUBE50000

---



- 
- For arming/disarming the control panel
  - Integrated proximity chip key reader
  - Switching partitions possible
  - Switching outputs possible
  - Power supply using batteries and/or external power supply
  - LEDs for displaying the current system status
- 

### Easy operation via code or proximity keyfob

The Secvest wireless control panel is an optional Secvest accessory. Every wireless control panel can be operated from your system via PIN code. It is possible to arm and disarm the panel via proximity keyfob.

### Flexible use in entrance areas

Up to 8 control panels can be integrated into the alarm system. These additional modules can be placed in various areas of the building. This provides added convenience for you, because Secvest can be armed and disarmed directly on the wireless control panel, without the need to go back to the central alarm panel every time.

In addition to internal arming or arming individual sub-areas, you can also switch a single output, such as the garage door, if desired.

## Secvest Wireless Control Device

Art.-Nr. FUBE50000

### Technical Data

AC voltage supply	9-12V
Battery type	3 x AA (1,5 V Alkaline)
DC voltage supply	9-15V
Environmental class	II
Height	120mm
Housing material	ABS
Installation location	Indoors
Length	30mm
Max. battery life	2year(s)
Max. humidity	94%
Max. operating temperature	55°C
Max. receiving range (building)	30m
Max. receiving range (outdoors)	100m
Max. sending range (building)	30m

Max. sending range (outdoors)	100m
Min. operating temperature	-10°C
Modulation	FM
Net weight	0.176kg
Power consumption	100mA
Radio frequency	868MHz
Security level	2
Status display	4 Status LEDs for partitions
Tamper monitoring	Yes
Transmission power	10
Voltage monitoring	Yes
Width	120mm